

Gas Flow Lab Report

Haoze Pang

1019521

Department of Physics and Astronomy
The University of Manchester

Abstract

This experiment consists of 2 parts. In the first part, we estimated the viscosity, η of Helium and Argon in the laminar flow regime, where viscosity is a property associated with the velocity gradient of gases. Our calculated values are $\eta_{He} = 9 \cdot 10^{-6} \pm 1.29 \cdot 10^{-2} \text{N} \cdot \text{s}/\text{m}^2$ for Helium and $\eta_{Ar} = 4.1 \times 10^{-5} \text{N} \cdot \text{s}/\text{m}^2$ for Argon. In the second part, we computed the pumping speed, a property associated with the rate of gas flow, in a molecular flow environment. Our results are, $S_{He} = 3 \pm 10 \text{m}^3/\text{s}$ for Helium and $S_{Ar} = 2 \pm 10 \text{m}^3/\text{s}$ for Argon. In both parts of the experiment, our estimation is not precise due to the low resolution of the pressure gauge employed. However, if assuming the actual value of pressure lies in the centre of our error bar, the calculated value is reasonably accurate compared to some reference data.

1 Introduction

In this experiment, the researcher tries to determine the properties of Helium (He) and Argon (Ar) gas by analysing the pressure in a thin tube as gases flow through it.

The researcher divided this experiment into two parts. In the first part, the experimenter created a laminar flow environment using a long tube and determined the viscosity of both gases. In the second part of this experiment, the experimenter created a molecular flow environment in a short tube. He then determined He and Ar's pumping speed by measuring the tube's pressure.

2 Theory

2.1 Laminar Flow Theory

Laminar flow is a type of gas flow that is steady, streamlined, and without swirls. In such a flow regime, layers of gas with varying velocities exist. The speed of gas in the middle layer is moving fastest. The rate decreases as it moves toward the walls of the tube and reaches zero at the wall. A force is associated with this velocity gradient and is characterised by viscosity η .

Now, we introduce theories that determine viscosity. Poiseuille's Equation,

$$Q = \frac{\pi * a^4 * (p_{in}^2(t) - p_{out}^2)}{16\eta l}, \quad (1)$$

relates the viscosity of the gas, the pressure difference, the dimensions of the tube the gas flows through, and its flow rate. Here, a is the radius, and l is the length of the tube. p_{in} is the pressure at the input end of the tube, and p_{out} is the pressure at the output end of the tube. In our laminar flow experiment, p_{out} is the atmospheric pressure. We also know that

$$Q = -V_{in}p_{in}(t)t. \quad (2)$$

Equating equation 1 and 2, then integrating, we obtain

$$\ln\left(\frac{p_{in}(t) - p_{out}}{p_{in}(t) + p_{out}}\right) = -\frac{\pi a^4 p_{out}}{8\eta l V_{in}} \cdot t + C \quad (3)$$

So, if we plot $\ln\left(\frac{p_{in}(t) - p_{out}}{p_{in}(t) + p_{out}}\right)$ as a function of time, we can use the gradient of the best-fit line (m) to determine the viscosity of a gas. From equation 3 can deduce that

$$\eta = -\frac{\pi a^4 p_{out}}{8ml V_{in}}. \quad (4)$$

2.2 Molecular Flow Theory

In laminar flow, the difference in pressure between two ends of the tube is sufficiently low that gas particles move slowly. The result is that collisions mainly occur between gas molecules and the wall. Here, the rate of gas flow is proportional to the input pressure and is given by the equation

$$Q = S p_{in}(t). \quad (5)$$

The proportionality constant S is referred to as pumping speed. Equating 5 with Poiseuille's Equation and integrating, we have

$$\ln(p_{in}(t) - p_r) = -\frac{St}{V_{in}} + C, \quad (6)$$

where p_{in} is the input pressure as a function of time, p_r is the residual pressure, and V_{in} is the volume of gas.[1]

3 Methods

3.1 Preparation

We set up the equipment as the figure shows.

[scale=0.3]GasFlowapparatus.png

Figure 1: In the experiment, gas flow through a narrow tube, RT1. PT1, which has a higher range, is the gauge used in the Laminar Flow trial. PT2, which has a lower measure range, is the gauge employed in molecular flow measurement.[1]

Now, we attempt to determine the input volume V_{in} and atmospheric pressure, p_0 , which corresponds to p_{out} in the laminar flow experiment. We operated the equipment in the following order. First, we closed all valves. Then, we opened IV 1 and IV 3. We continued to open IV 2 and pump Helium in, and as the reading on PT1 stabilises, recorded it as p_x . Here, we recorded p_x , the pressure corresponding to a volume, which is the sum of the standard valve and the input volume. We closed all valves, and opened IV 4, IV 5, and IV 3. As the reading on PT1 stabilises, we recorded it as p_0 . Here, we measured the atmospheric pressure, which corresponds to the volume of the standard valve.

Assuming constant temperature, we have ideal gas law in the form

$p_1 \cdot V_1 = p_2 \cdot V_2$ In this measurement,

$p_0 \cdot V_s = p_x \cdot (V_s + V_{in})$, where $V_s = 150\text{cm}^3$ is the volume of the standard valve.

Solving the equation above, we determined,

$$V_{in} = 6 \times 10^{-4} \pm 6 \cdot 10^{-3}\text{m}^3.$$

Note that in the calculation of the uncertainty on V_{in} , we ignored the term V_s as the uncertainty on it is much smaller than the other two terms.

3.2 Laminar Flow

In this part of the experiment, the experimenter operated the apparatus in the following order to create a laminar flow environment. We first placed a long tube in RT 1, then closed all valves. (step: Start). We proceeded to open Quick Action Valve (IV 4) and Bypass Valve (IV 3), next opened Vacuum Pump Isolation Valve (IV 6). We subsequently waited for the reading on PT2 to drop to a magnitude of 10^{-3} . The steps above aim to evacuate any residual gas in our narrow tube.

We then closed IV 6, IV 4, and IV 3, and opened IV 2 and pump Helium in. (step: Pump gas) When the reading on PT1 reaches approximately 2000 mbar, we closed IV2. We started to record data at this point with a minimum interval of 0.5s. , then opened Vent Isolation Valve (IV5). We waited until the reading on PT1 reaches atmospheric pressure, in this particular experiment, 1024 mbar (step: End) We repeated step 'Start' to 'End' twice, changed the gas in step 'Pump gas' to Ar, and repeated step 'Start' to 'End' thrice to collect data on Ar.

3.3 Molecular Flow

In this part of the experiment, we operated the equipment in the following order to create a molecular flow environment.

1. Close all valves.
2. Open IV 4 and IV 6
3. Wait for the readings on PT2 to drop to a magnitude of 10^{-4}
4. Close IV 4
5. Open IV 2 and pump gas in until the pressure is about 5 to 8 mbar
6. Start to record data with minimum logging interval of 45s

Repeat this process but change the gas in step 5 to Ar.

4 Calculations and Results

4.1 Laminar Flow

The experimenter plotted $\ln\left(\frac{p_{in}(t)-p_{out}}{p_{in}(t)+p_{out}}\right)$ against time t and using LSFR to generate a best fit line.

The weighted mean on the gradient m is $-2.5 \times 10^{-2} \pm 6.83 \times 10^{-4} \text{ s}^{-1}$. Checking the manufacture notes on the long tube, we obtain the following data: $a = 0.01 \pm 0.005$

Number of trials	Gradient	Reduced χ^2
1	$-2.52 \times 10^{-2} \pm 9.34 \times 10^{-4}$	0.01
2	$-2.54 \times 10^{-2} \pm 1.25 \times 10^{-3}$	0.01
3	$-2.52 \times 10^{-2} \pm 1.67 \times 10^{-3}$	0.01

Table 1: This table shows the gradient (m) and reduced χ^2 of the best-fit line of our data on He.

mm, $l = 30.0 \pm 0.5$ mm.

Substituting values to equation 4, we reckon $\eta_{He} = 9 \cdot 10^{-6} \pm 1.29 \cdot 10^{-2} \text{N} \cdot \text{s}/\text{m}^2$.

Similarly, we have the data on Ar as the following:

Number of trials	Gradient	Reduced χ^2
1	$-1.68 \times 10^{-2} \pm 6.15 \times 10^{-4}$	0.10
2	$-1.65 \times 10^{-2} \pm 6.13 \times 10^{-3}$	0.09
3	$-1.64 \times 10^{-2} \pm 6.08 \times 10^{-3}$	0.09

Table 2: This table shows the gradient (m) and reduced χ^2 of the best-fit line of our data on Ar.

The weighted mean on the gradient m is $-1.65 \times 10^{-2} \text{ s}^{-1}$. Substituting values to equation 4, we reckon $\eta_{Ar} = 4.1 \times 10^{-5} \text{N} \cdot \text{s}/\text{m}^2$.

4.2 Molecular Flow

Now, we calculate the pumping speed of He. We plotted $\ln(p_{in}(t) - p_r)$ against time, with a time interval of $1500\text{s} < t < 3000\text{s}$, which we determine as the timescale where the gas glow is characterised as molecular flow. (Note that we calibrated our data by multiplying a different constant for other gases' original data.) Using LSFR, we generated the best fit line on the data.

[scale=0.5]Molecular_{Helium}bestfitline.png

Figure 2: This graph shows the best-fit line of our data.

We have the gradient $m = -4.840^{-5} \pm 4.5 \times 10^{-6}$. Also, from equation 6, we know that

$$S = -mV_{in}. \quad (7)$$

Substituting m , we obtain

$$S_{He} = 3 \pm 10 \text{m}^3/\text{s}. \quad (8)$$

We identified the uncertainty in V_{in} as the main factor contributing to the uncertainty of S .

Likewise, we now compute the pumping speed of Ar. We generated the best-fit line, this time choosing $1750\text{s} < t < 2750\text{s}$.

[scale=0.5]MolecularArgon.png

Figure 3: This graph shows the best-fit line of our data. The gradient of the best fit line is $-2.69 \times 10^{-4} \pm 2.2 \times 10^{-5}$

Following a similar reasoning, we reckon the pumping speed of Ar is

$$S_{Ar} = 2 \pm 10 \text{m}^3/\text{s}. \quad (9)$$

5 Discussion

5.1 Laminar Flow

In the laminar flow experiment, our result is not precise. The uncertainty of the viscosity is large. It has a magnitude of about 10^{-2} , whereas the reference value of the viscosity of both gases at 20°C is about a magnitude of 10^{-5} .

Now, we try to analyse factors contributing to the uncertainty of η . Five factors (a^4 , p_{out} , m , V_{in} , and l) contributed to the uncertainty of viscosity. $\sigma_{a^4} = 1 \times 10^{-17}$, $\sigma_{p_{out}} = 256$, $\sigma_{V_{in}} = 0.006$, $\sigma_l = 5 \times 10^{-4}$, and $\sigma_m = 6.83 \times 10^{-4}$. $\sigma_{p_{out}}$ made for most of the uncertainty in viscosity. This is due to the intrinsic resolution of PT 1, which has an uncertainty of 2.5%. Therefore, a possible way of improving the precision of the result is to use a gauge with more accuracy.

Assuming the actual measure lies in the centre of our error bar, our data is fairly accurate. At 20°C , the reference value for η_{He} is $1.96 \times 10^{-5} \text{N} \cdot \text{s}/\text{m}^2$, and for η_{Ar} is $2.23 \times 10^{-5} \text{N} \cdot \text{s}/\text{m}^2$

5.2 Molecular Flow

Similar problems with uncertainty appeared in the estimation of pumping speed. The input volume is the major contributing factor to the uncertainty of pumping

speed. This, however, is also linked to the resolution of the pressure gauge, because we computed the input volume using the ideal gas law, which involves pressure.

Also, if assuming the actual value of our measurement lies in the centre of the error bar, our estimation is fairly accurate. The theoretical value of S_{He} is $2.6\text{m}^3/\text{s}$, and S_{Ar} is $8.6\text{m}^3/\text{s}$. [2]

References

- [1] A Russell I Duerdoth. *GAS FLOW THROUGH NARROW TUBES*. 2018. URL: https://online.manchester.ac.uk/webapps/blackboard/execute/content/file?cmd=view&content_id=_13933126_1&course_id=_73074_1 (visited on 12/2022).
- [2] The Engineering Toolbox. *Gases - Dynamic Viscosities*. 2014. URL: https://www.engineeringtoolbox.com/gases-absolute-dynamic-viscosity-d_1888.html (visited on 12/2022).